

HT381



Interactive Setup Guide


Initial Setup

Product Overview

Additional Options

< Back




Product Overview - Earbuds



Next

< Back

Product Overview - Transmitter



Continue to setup

< Back

Start
Over



Plug in the transmitter

Use the provided power cable to plug the transmitter into a power source near your TV.



It's plugged in

< Back

Start
Over



Turn on the earbuds to connect

Slide the earbuds' power switch to the "ON" position and hold it close to the transmitter. They'll automatically connect and their LEDs will turn solid green.



Solid green—
they're connected

No solid light

< Back

Start
Over



Check the batch number

The reconnection process varies depending on your batch. Check the bottom of your transmitter to find your batch number.



Batch is **before T24B1**

Batch is **T24B1 or later**

< Back

Start
Over



Put the earbuds in pairing mode

Press & hold the "AMBIENT" button for 5 seconds until the LED indicator starts rapidly flashing green.



It's flashing green

Need help

< Back

Start
Over



Unplug & reconnect the transmitter to connect

With the earbuds close by, unplug the transmitter, then plug it back in. They will connect within a few seconds, and their LEDs will turn solid green.



Solid green—
they're connected

Still no solid light

< Back

Start
Over



Put the earbuds in pairing mode

Press & hold the "AMBIENT" button for 5 seconds until the LED indicator starts rapidly flashing green.



It's flashing green

Need help

< Back

Start
Over



Put the transmitter in pairing mode to connect

Press & hold the transmitter's "MODE" button for 5 seconds or until the bottom LED starts flashing green. The earbuds & transmitter will connect within a few seconds, and their LEDs will turn solid green.



Solid green—
they're connected

Still no solid light


< Back

Start
Over



Turn your TV on & start playing something

It can be anything as long as it has some kind of sound.



TV sound is on


< Back

Start
Over



Select an audio output option


Check the back or side of your TV to check the available audio output ports.




Optical (OPT)




(Recommended)



AUX



RCA



Others



< Back

Start
Over



Connect the transmitter to your TV via optical

Plug one end of the provided optical cable into your TV, and the other end into the transmitter's optical port.



Note: Be sure to plug in the optical cable with the correct side up, as it's directional.

Connected via optical

< Back


Start
Over



Change your TV's sound settings

Use your TV remote to access the sound settings, then choose the following:

TV's Sound Settings

A stylized illustration of a television set with a screen. The screen displays a settings menu with the following text:

Settings
> Sound / Audio
> Output
> **Optical**

The word "Optical" is bolded, indicating it is the selected option.

"Optical" is selected

Need help

< Back

Start
Over



Check your earbuds for sound

You should be able to hear TV audio through your earbuds. If not, try adjusting the volume on the earbuds using the volume wheel.

Earbuds are working

Earbuds are not working

< Back

Start
Over



TV sound settings guide

Settings vary from brand to brand. We've included guides for some of the most popular TV brands below.

SAMSUNG

SONY



ROKU

VIZIO

Settings are
successfully changed

Need help


< Back

Start
Over



Connect the transmitter to your TV via AUX

Plug one end of the provided AUX cable into your TV, and the other end into the transmitter's AUX port.



Connected via AUX

< Back

Start
Over



Change your TV's sound settings

Use your TV remote to access the sound settings, then choose the following:

TV Sound Settings



Settings
> Sound / Audio
> Output
> **Headphones**

A simple black silhouette of a TV stand with a central rectangular cutout.

"Headphones" is selected

Need help

< Back

Start
Over



Check your earbuds for sound

You should be able to hear TV audio through your earbuds. If not, try adjusting the volume on the earbuds using the volume wheel.

Earbuds are working

Earbuds are not working

< Back

Start
Over



Connect the transmitter to your TV via RCA

Use the provided RCA to AUX adapter to connect the RCA end to your TV and the AUX end to the transmitter. Valid RCA ports are labeled "AUDIO OUT."




Connected via RCA

< Back


Start
Over




Other connection options



HDMI ARC



AV Receiver



TV Box



Not listed

< Back

Start
Over



If your TV only has an HDMI ARC port...

You'll need to purchase the HAX05 to connect your HT381. Tap the box below to access the purchase link.



Otherwise, you'll need to connect your HT381 another way.

I'll connect another way

< Back

Start
Over



Note about AV Receiver connections

Please be aware that connecting via an AV receiver may mute your TV's speakers.

Connect to AVR anyways

< Back

Start
Over



Connect the transmitter to your TV via a TV box

Although not recommended, you can connect the transmitter to your TV box as a last resort.

Note: Connecting via TV box restricts audio to only what's played through the box.

Connect to TV box

< Back


Start
Over



Additional Options




Ambient Mode



L/R Balance



Add Earbuds



Charging Tips



< Back

Start
Over



Activating Ambient Mode

Ambient Mode amplifies surrounding sound to help you hear more clearly.

Toggle Ambient Mode by pressing the "AMBIENT" button once. The LED will turn red when Ambient Mode is activated and green otherwise.



Got it

< Back

Start
Over



Left / Right Balance Control

Use the spinner on the back of the earbuds to adjust the left / right sound balance to your liking.



Got it

< Back

Start
Over



Charging Tips

Charge the earbuds by placing them in the dock, or swap in the spare battery while charging the other for uninterrupted listening.



Got it

< Back

Start
Over



Check the batch number

The process to add more earbuds varies depending on your batch. Check the bottom of your transmitter to find your batch number.



Batch is **before T24B1**

Batch is **T24B1 or later**



Reach out to us!

Please contact us for more information about adding additional HT381 earbuds to your set.

Contact us

< Back

Start
Over



Add more HT381 earbuds

You'll need to purchase an extra pair of earbuds first. Tap the box below to access the purchase link.



Got it, take me to setup

No need for setup

< Back

Start
Over



Put the earbuds in pairing mode

Turn on the earbuds, then press & hold the "AMBIENT" button for 5 seconds until the LED indicator starts rapidly flashing green.



It's flashing green

Need help

< Back

Start
Over



Put the transmitter in pairing mode to connect

Press & hold the transmitter's "MODE" button for 5 seconds or until the bottom LED starts flashing green. The earbuds & transmitter will connect within a few seconds, and their LEDs will turn solid green.



Solid green—
they're connected

No solid light

< Back


Start
Over



Reach out to us for help!

You can email us directly at **support@avantree.com**, or click the button below to redirect to our support page.

We'll get back to you within 1 business day!



Get support

< Back

You're done!

We hope you enjoy your experience with the HT381!

If you ever need anything, please don't hesitate to reach out to us at support@avantree.com



Additional Options

Start Over