HT5009 Plus



Interactive Setup & Support Guide

Version 1.6

Start Setup

Main Menu

- 1. Before You Start
- 2. <u>Buttons & Indicators</u>
- 3. How to Charge
- 4. Connect via Base (Recommended)
- 5. Connect via TV Bluetooth
- 6. Boost Volume
- 7. Advanced Features
- 8. Recommend Use With
- 9. Troubleshooting
- 10. Register Your Product
- 11. Live Agent Help
- 12. Rate This Guide
- 13. Share Your Feedback




1. Before You Start

- Recommended to use as a set for easy pairing, low latency and high volume.
- Headphones can also connect directly to Smart TV via Bluetooth.
- Transmitter can connect up to two headphones. You can buy our Audition 3.

2. Buttons & Indicators


2.1 Headphones



- 1 Pair: Hold to "PAIR" 3s → LED A blinks red & blue
- ② Reset: Hold + & 8s → LED A turns pink
- 3 Reconnect: Press once
 Mute / Unmute: Double-click
- 4 Balanced / Clear Voice: Press once

2. Buttons & Indicators

2.2 Transmitter



- 5 Reset: Hold + & 5s → LEDs B & C
 turn green
- 6 Pair with 2nd headphone: Hold ②
 2s → LED ③ blinks white & green
 Connected: LED ⑤ stays white
- 7 OPT volume boost: Slide to "Boost"

3. How to Charge

- Use USB-C (5V, 0.5~2A)
- Charging: LED stays red
- Full: LED off (~2 hrs)
- Playtime: up to 50 hrs


Note: Headphones auto power off in dock. Toggle OFF → ON to turn on.








Choose Mode



Connect via Base (Recommended)




Connect via TV Bluetooth







Select Connection Type



(Recommended)









4.1 Connect Cables

12 Plug Optical cable into TV's Optical Out & transmitter's OPTICAL.








4.1 Connect Cables

2\textstyle Plug USB-C cable into transmitter and TV.







4.2 Adjust TV Sound Settings

1\(\text{So to: Settings > Sound > Sound } \)
Output, select **Optical**.

2\omega Set audio format to PCM to avoid no sound.



Not sure how? Visit our <u>TV Sound Settings Guide</u>

Next

4.3 Connect headphones and transmitter

1⊠ Slide power switch to **ON**.

21 Wait 5s. Both LEDs turn **solid** when connected. If not solid, press on transmitter.









4.1 Connect Cables

12 Plug AUX cable into TV's headphone jack & transmitter's AUX.



4.1 Connect Cables

2\textstyle Plug USB-C cable into transmitter and TV.








4.2 Adjust TV Sound Settings

Go to: Settings > Sound > Sound Output, select **Headphones**.



4.3 Connect headphones and transmitter

1⊠ Slide power switch to **ON**.

21 Wait 5s. Both LEDs turn **solid** when connected. If not solid, press on transmitter.









4.1 Connect Cables

111 Use RCA ports labeled Audio Out.

- RCA adapter NOT included.
- Contact us for a free RCA to AUX adapter if needed.





4.1 Connect Cables

2\textstyle Plug USB-C cable into transmitter and TV.







4.2 Adjust TV Sound Settings

Go to: Settings > Sound > Sound Output, select **Headphones**.



4.3 Connect headphones and transmitter


1⊠ Slide power switch to **ON**.

21 Wait 5s. Both LEDs turn **solid** when connected. If not solid, press on transmitter.





5.1 Keep Transmitter OFF







5.2 Enter TV Bluetooth Settings

Go to: Settings > Sound > Sound Output, select **Bluetooth Speaker List**.



Not sure how? Visit our <u>TV Bluetooth Settings Guide</u>

Next



5.3 Put Headphones into Pairing

1⊠ Slide power switch to **ON**.

21 Hold to "PAIR" for 3s.

LED blinks red & blue → ready to pair.








5.4 Connect to TV

Select "Avantree AS19" from TV's Bluetooth Speaker List to connect.



5.5 Reconnection Tips


- Slide power switch to ON.
 Headphones will auto-connect to your TV.
- If not, select "Avantree AS19" in TV's Bluetooth list.

Note:

- Ensure transmitter is off.
- Headphones auto power off in dock. Toggle OFF→ON to turn on.

6. Boost Volume

- 112 Adjust headphone volume.
- 2\overlightarrow{\text{Slide to "Boost"}} to increase OPT volume by up to 6dB, if connecting via base.



7.1 Add 2nd Headphone

- 1☑ Press & hold ② n transmitter for
 2s. LED ② blinks white & green.
 → ready to pair.
- 21 Put 2nd headphone into pairing mode. Once connected, LED (2) stays white.





7.2 Use Headphone With Phone/PC

- **1**⊠ Turn off transmitter.
- 2\mathbb{Images} Turn on headphones, hold to "PAIR" for 3s. LED blinks red & blue.
- 3\(\mathbb{Z}\) Turn on Bluetooth, select "Avantree AS19". LED off when connected.



7.3 Use With TV Speaker

Some TVs let you play sound through **TV speakers** and **headphones** at the same time.


- Works by default on some models.
- Others need PCM + TV Speaker selected in settings.
- See <u>FAQ</u> for step-by-step help.





7.4 Bypass to Soundbar

Bypass works only with matching input / output, e.g., Optical for both TV and soundbar.





8. Recommend Use With

These add-ons work great with your HT5009 Plus:



AS50Q



Audition 3



NB16-Q



AS70P



Infinity



9. Troubleshooting

No Sound?

Ensure headphones and transmitterare connected (LED 11 stays white)

Set audio format to PCM.

 Headphone-Base Disconnected?
 Toggle OFF to ON to turn on headphones after charging.

Ensure headphones aren't connected to other devices, then pres non transmitter to reconnect.

Cannot Connect to TV Bluetooth?
 Turn off the transmitter.

More Troubleshooting & FAQs /



10. Register Your Product

Register now to:

- Extend warranty to 24 months-FREE.
- Enjoy priority service support.

Register Now ↗





11. Live Agent Help

We'll respond within **1 business day**Quick support options:

- X Email: support@avantree.com

- ∠ Live chat ∠





12. Rate This Guide

Thanks for choosing HT5009 Plus!

We hope this guide helped you get started.

Your quick rating helps us improve:











13. Share Your Feedback

We've supported hearing-impaired customers for **20+** years.

Did we help you? Leave a quick review on Amazon to support us!

Select your store:

- Mazon US
- Mazon UK
- M Amazon CA
- Amazon AU