Quartet 2



Interactive Setup Guide

Version 1.3

<u>Advanced Setup & FAQs</u>

Buttons & Indicators

Initial Setup



Warning

✓ You're about to leave this setup guide and visit an external link.


To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7

Buttons & Indicators

Headphones:


Quartet 2 headphones deliver crystalclear TV sound for an immersive, effortless listening experience.



Buttons & Indicators

Transmitter:

The Avantree Flex Base transmitter streams TV audio to its headphones without lip-sync delays.



Continue to setup





What's in the box?



✓ 4*Headphone
s



Transmitter



✓ 4-in-1
Charging Cable



✓ PowerCable forTransmitter



✓ Optical Audio Cable



✓ AUX 3.5mm Audio Cable

Continue

Buttons & Indicators





Connect via optical

- Plug one end of the cable into TV's "Optical Digital Audio Out" port.
- 2 Plug the other end into transmitter's "Optical" port.





Connected

I don't have optical



Plug in the transmitter

★ Prepare a USB power adapter, plug the USB-C cable into a power source near the TV.




*No spare USB power adapter? <u>Contact us</u> for assistance.

Switch input to "OPT/AUX"

- **I** Slide power switch to "ON."
- 2 Slide Audio Input Switch to "OPT/AUX".
- 3 Check LEDs

OPT,)))), Normal will light up.







Select the correct audio settings

- Using your TV remote, go to:
- **→** Settings → Sound → Sound Output.
- ✓ Select Optical.



Not sure how? Visit our <u>TV Sound Settings Guide</u>



Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7





Ensure "PCM" is selected

✓ Change "Audio Format" to PCM.



Not sure how? Visit our <u>TV Sound Settings Guide</u>



Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7






Connect the headphones

1 Power ON Slide power switch to "ON." Wait for **3-5** seconds.

2 Once connected, the LED will turn solid blue .



Connected

Troubleshoot

Test for sound

- (1)) Play a TV show or movie and check for sound through the headphones.
- ✓ Tip: To stop sound from your TV speakers, go to Settings → Audio and select "TV Speakers Off."

Continue

Troubleshoot

If there's no sound...

Q Check the cable connections and make sure they are fully plugged in.

Make sure the TV's audio output is set to the correct source (optical, AUX, or RCA).

Try changing the TV's audio format to PCM (for optical connections).

Restart the TV, transmitter, and headphones.

Continue


Need help



Enable BT on your device

The **Phone mode** is designed to connect with Bluetooth-enabled audio source devices, not output devices.

Turn on Bluetooth on your device.



Not sure how? Contact the device manufacturer or visit our <u>TV Bluetooth Settings Guide</u>



Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7



Plug in the transmitter

★ Prepare a USB power adapter, plug the USB-C cable into a power source near the TV.



*No spare USB power adapter? <u>Contact us</u> for assistance.





Switch input to "Phone"

- I Slide power switch to "ON."
- 2 Slide Audio Input Switch to "Phone".
- The "Phone" indicator will start flashing, ready to pair with your audio source device.



Select "Avantree Flex Base"

Q Select the transmitter from your device's Bluetooth list.

Wait for "Connected" message.




Connected

Connect the headphones

Power ONSlide power switch to "ON." Wait for3-5 seconds.

2 Once connected, the LEDs will turn solid.



Connected

Troubleshoot



Connect via AUX

- Plug one end of the AUX cable into the TV's headphone jack.
- Plug the other end into the transmitter's "AUX" port.





Connected

Plug in the transmitter

★ Prepare a USB power adapter, plug the USB-C cable into a power source near the TV.



*No spare USB power adapter? <u>Contact us</u> for assistance.

Switch input to "OPT/AUX"

- **Slide** power switch to "ON."
- 2 Slide Audio Input Switch to "OPT/AUX".
- (3) Check LEDs: AUX, (*))), Normal will light up.







Select the correct audio settings

- Using your TV remote, go to:
- → Settings → Sound → Sound Output.
- Select Headphones.





Connect the headphones

Power ONSlide power switch to "ON." Wait for3-5 seconds.

2 Once connected, the LED will turn solid blue .



Connected

Troubleshoot

Connect via RCA

⚠ Note

- RCA adapter is NOT included.
- Use RCA ports labeled "Audio Out."
- Contact us for a free RCA to AUX adapter if needed.



Note: Contact us for a free RCA to AUX adapter if needed.

Connected

Contact us

Minimize interference

- Interference may occur due to nearby devices operating on the 2.4GHz frequency, such as Wi-Fi routers, access points, or even a working microwave oven.
- To minimize disruptions, please ensure these devices are positioned as far away as possible from the headphones and transmitter.



Connected

Troubleshoot





Transmitter enter pairing


Press & hold the •>>>) button for 3 seconds until the Add Devices •>>>) LED flashes



Pair your headphones

Hold the OFF/ON/PAIR button in the PAIR position for 5 seconds until the LED flashes (pairing mode).

Place them close, headphones & transmitter will connect (solid LEDs).



Connected


Need help

Switch audio modes

Two Methods

Headphones: Press the **EQ button** to switch between **Clear Voice** (enhances speech) & **Balanced** Mode.


Transmitter: Press "+" and "-" simultaneously to switch between Normal, Voice Clear, and Bass EQ modes. (**)Not loud enough? Press "+" or "-" to adjust the volume within the selected mode.)









Other connection options











If your TV only has an HDMI ARC port...

You'll need to either purchase the HAX05 to connect your Quartet 2, or exchange it for the HDMI ARC-supporting Opera Plus.





Otherwise, you'll need to connect your Quartet 2 another way.

Connect another way



Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7



Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7





Reach out to us for help!

You can email us directly at **support@avantree.com**, or click the button below to redirect to our support page.

We'll get back to you within 1 business day!

Get support





Warning

✓ You're about to leave this setup guide and visit an external link.

To come back here again, please use your browser's "back" button or re-scan the QR code on your device.

Proceed 7





You're done!

We hope you enjoy your experience with the Quartet 2!

If you ever need anything, please don't hesitate to reach out to us at support@avantree.com

<u>Add FREE 24-month coverage!</u>

