



VoxAmp Lite

Portable Voice Amplifier
with Wireless Mic




Interactive User Guide

Version 2.3



First Time Setup



Troubleshooting

< Back



Main Menu

1. Power & Charge
2. Use Voice Amplifier
3. Avoid Feedback
4. Use Bluetooth Speaker
5. Use USB Drive
6. Voice Recording & Playback
7. Buttons & Indicators
8. Advanced (Optional)
 - Talk with Background Music
9. Troubleshooting
10. Register & Support

Next




1. Power & Charge

Amplifier & Mic

- Charge BOTH amplifier & mic before use
- USB-C charging (5V, 1A)
- **Red** LED on = Charging
- Off = Fully charged (~2.6 hrs)

Next



< Back




Menu

2. Use Voice Amplifier

- 1 Turn on amplifier.
 - 2 Turn on mic → LED blinks white.
- ✓ Connected: Mic LED turns **solid white**.



Next







3. Avoid Feedback

- Keep mic at least **1 m** away from amplifier
- Never point mic at the amplifier
- Lower volume if you hear a squeal

Next




4. Use Bluetooth Speaker

- 1 Turn on amplifier.
 - 2 Press **M** to switch to Bluetooth mode.
→ LED blinks **blue** (pairing)
 - *If not, hold **M** to pair.*
 - 3 Turn on Bluetooth and select "Avantree VoxAmp Lite".
- ✓ Connected: LED turns **solid blue**.



Next



5. Use USB Drive

① Turn on amplifier.

② Insert USB drive.


→ Music plays automatically.

*If not, press **M** to switch to USB Drive mode.*

③ Hold **+** / **-** → Next / previous track.



Next



< Back



Menu



6. Voice Recording & Playback

Record once → Loop playback

Best for:


- Teaching
- Repeating instructions

Next





6.1 Voice Recording

- 1 Turn on amplifier & mic.
- 2 Insert USB drive.
- 3 Hold ▶ to start recording.
(LED blinks slowly).
- 4 Hold ▶ again to stop.





 *Recording will play automatically in loop.*

Next




6.2 Playback

- Double-press  → playback
- Press **M** → exit playback
- Hold  during playback → delete recording


 *Playback loops within the recording folder.*

Next



7. Buttons & Indicators

7.1 Amplifier



① M Button – Mode Switch

- Press M = Switch Amplifier/Bluetooth/USB drive (USB drive inserted)



② ▶ Button

- Press → Play/pause
- Hold → Start/stop recording (USB drive required)
- Double-press → Recording playback


A Bluetooth

- ✓ Solid → Connected
- ⚠ Fast blinking → Not connected

Next



7.2 Microphone





B LED

✓ Solid → Connected

⚠ Blinking → Not Connected

[👉 Full Buttons & Indicators Guide](#)

Next





8. Advanced (Optional)



8.1 Talk with Background Music

- Play music via Bluetooth
- Speak into mic → voice overlays music

Best for:

- Small groups
- Presentations

Next



< Back




Menu

Rate This Guide

Your feedback helps us improve this guide for everyone.

It only takes a moment.



Next




9. Troubleshooting



Common Issues

- No sound
- Avoid feedback
- Avoid interference

 [More FAQ & Help](#) ↗

 *Still need help?* [Contact support](#) ↗

Next





10. Register & Support

Register Your Product

Extended warranty & get updates.

[Get 24M Warranty](#)

Need help? Contact Us



Email

support@avantree.com



Call



USA (Toll Free)

[+1 800 232 2078](tel:+18002322078)



[Other Regions](#)



[Chat](#)

