

Audikast 4



Interactive Setup Guide

Version 1.5


Start Setup

[< Back](#)



Main Menu

1. [Before You Start](#)
2. [What's in the Box](#)
3. [Buttons & Indicators](#)
4. [Compatible Hearing Aids](#)
5. [Use With App](#)
6. [Use With Samsung Phone](#)
7. [Connect With TV](#)
8. [Advanced Features](#)
9. [Common Errors & Fixes](#)
10. [Register Your Product](#)
11. [Live Agent Help](#)
12. [Rate This Guide](#)

[Next](#)



1. Before You Start

- Sends audio to Auracast devices
- Supports hearing aids for multi-play → [See Compatible Devices](#)
- Default mode: Classic Bluetooth
Switch to Hearing Aid:
Press  once. → LED blinks **orange** every 5s. If not, hold  for 3s.

< Back

Back to
Menu



2. What's in the Box

Inside your package, you'll find:



☒ Audikast 4
Transmitter



☒ Type C
power cable



☒ Optical
audio cable



☒ AUX 3.5mm
audio cable

Next



3. Buttons & Indicators



Enter Auracast: Press  once.

Hold  for 3s to switch between:

- Hearing Aid:


 **blinks orange every 5s**

- Auracast Standard:

 **stays orange**

Enter Bluetooth: Press  once.

Next



4. Compatible Devices

4.1 Auracast-Enabled

Connect via your hearing aid's companion [app](#), or an Auracast

[Assistant \(e.g. Samsung S24:](#)

- ReSound Nexia,
- ReSound Viviva
- ReSound Savi
- Beltone Commence
- Beltone Envision
- Beltone Serene
- GN Danalogic Extend
- Jabra Enhance Pro 20
- Jabra Enhance Pro 30
- ...



4. Compatible Devices

4.2 Auracast-Ready

Requires [an Auracast Assistant \(e.g. Samsung S24\)](#) to connect:

- Starkey Edge AI
- ...

Note:

Device support is updated regularly. Check [FAQ](#) for the latest list.

< Back

Back to
Menu



4. Compatible Devices

4.3 Choose How to Use




With App



With Samsung Phone

< Back

Back to
Menu



5. Use With App

1☒ Connect Audikast 4 to power.


2☒ Turn it **ON**.

3☒ Press  once. → Auracast LED
blinks orange every 5s.

If not, hold  for 3s.


4☒ On your hearing aid's app: go to
LE Audio/Auracast.

5☒ Tap **Audikast 4_XXXX**, then enter
the password.



 **Passcode**

Next



6. Use With Samsung Phone

6.1 Power Audikast 4

[Find Samsung Phone Alternatives ↗](#)


1☒ Connect Audikast 4 to power.

2☒ Turn it **ON**.

3☒ Press  once. → Auracast LED
blinks orange every 5s.


If not, hold  for 3s.


Next



6. Use With Samsung Phone

6.2 Connect Hearing Aids

- 1☒ Turn on Bluetooth on the phone, then select your hearing aids.
- 2☒ Tap  and turn on LE Audio.
- 3☒ Tap **Listen to Auracast broadcast** > **Audikast 4_XXXX**, then enter the password.




< Back

Back to
Menu




7. Connect With TV

Select audio source connection:



Optical

(Recommended)



AUX

< Back

Back to
Menu



7. Connect With TV

7.1 Connect the Optical Cable

Plug in the optical audio cable to connect Audikast 4 and your TV.



Next

< Back

Back to
Menu



7. Connect With TV

7.2 Set TV Audio Output

1☒ Go to Settings > Sound > Sound Output, then select **Optical**.

2☒ Set output audio to **PCM** to avoid **no sound**.

3☒ Play a video → The audio signal stays **solid**.




→ See audio setup by brand.

Next

< Back

Back to
Menu



7. Connect With TV

7.1 Connect the AUX Cable


Plug in the AUX audio cable to connect Audikast 4 and your TV.



Next

< Back

Back to
Menu



7. Connect With TV

7.2 Set Up TV Audio


1☒ Go to Settings > Sound > Sound Output, then select **Headphones**.

2☒ Play a video → The audio signal stays **solid**.



→ See audio setup by brand.

Next



8. Advanced Features

8.1 Auracast Standard Setup

Auracast audio devices like [Avantree Infinity](#) and [HomeBuddy](#) support both Auracast modes.

For better sound, switch to **Auracast Standard** mode:

Press and hold  for 3s.



→ LED stays **orange**.

Need help? [Contact us](#) to set it up.



8. Advanced Features

8.2 Bluetooth Setup

- 1☒ Disable phone bluetooth, then
[enter pairing on headphones.](#) ↗
- 2☒ Plug in Audikast 4 and turn it **ON**.
- 3☒ Press  once. → LED blinks **red** & **blue**. If not, hold  for 2s
→ Once connected, LED stays **blue**.



< Back

Back to
Menu



8. Advanced Features

8.3 Reset Bluetooth Pairing

1☒ Plug in Audikast 4 and turn it **ON**.

2☒ Press and hold **+** & **-** for 5s.

→ **All** LEDs stays on for 2s. →

Bluetooth LED blinks **blue** every 5s.

This will clear pairings and enter pairing mode.



Next



9. Common Errors & Fixes

- **Connection failed?**

Ensure your hearing aids are compatible. → Check [FAQ](#) for the latest list.

- **TV Audio Signal Valid?**

The audio signal must be solid.

If flashing:

- Check all cables are secure
- For Optical : Set TV audio to **PCM**
- For Aux: Set TV audio to **Headphones**

- **Still no sound?**


Make sure Audikast 4 is in Hearing Aid mode .

[More Troubleshooting & FAQ](#) ↗

Next

< Back

Back to
Menu



10. Register Your Product

Register now to:


- Extend warranty to 24 months—FREE.
- Enjoy priority service support.

[Register Now](#) ↗

You're Ready

< Back

Back to
Menu



11. Live Agent Help

We'll respond within **1 business day**

Quick support options:

☒ Email: support@avantree.com


☒ [Schedule callback ↗](#)

☒ [Submit a ticket ↗](#)

☒ [Live Chat ↗](#)

< Back

Back to
Menu



12. Rate This Guide

Thanks for choosing Audikast 4!

We hope this guide helped you get started.

Your quick rating helps us improve:

