### **Audikast 3**



# Interactive Setup & Support Guide

Version 1.6.1

Start Setup

#### Main Menu

- 1. Before You Start
- 2. What's in the Box
- 3. Buttons & Indicators
- 4. Connect Headphones
- 5. Connect to TV
- 6. Advanced Features
- 7. Recommend Use With
- 8. Troubleshooting
- 9. <u>Register Your Product</u>
- 10. Live Agent Help
- 11. <u>Rate This Guide</u>
- 12. Advocate for Us

## 1. Before You Start

Add wireless Bluetooth streaming to your TV with this easy-to-use transmitter

- Place the unit near your TV and a power outlet
- Works with Bluetooth headphones, earbuds, or speakers
- Check your TV for Optical, AUX, or RCA output
- Setup takes just a few minutes—no tech skills needed

## 2. What's in the Box

Inside your package, you'll find:



Audikast
Transmitter



✓ Type C
Power Cable



Optical
Audio Cable



AUX 3.5mm
Audio Cable

## 3. Buttons & Indicators



#### LED OPT/AUX:


✓ Solid = Valid audio signal

#### LED @:

- ✓ Solid = Connected
- Blinks red & blue = Pairing
- Blinks blue = Reconnecting

#### 4.1 Disable Phone Bluetooth

To avoid auto-reconnect, turn off Bluetooth on connected devices (e.g. phones).



### 4.2 Headphone Pairing

Not sure how? Select your brand.



















Other/ Speaker


#### 4.2 AirPods & AirPods Pro

AirPods 1, 2, 3 & AirPods Pro: With AirPods in the case, open the lid, then hold the button on the back for ~5s.

→ LED blinks white.



AirPods 4: **Double-tap** the front of the AirPods case. LED: green → **white** 




#### 4.2 AirPods Max

Press and hold the right noise control button for **5s**.

LED on the bottom blinks white.


→ Ready to pair.



#### 4.2 Bose QC Ultra


- 1 Turn on your headphones.
- Press and hold the power button.

  LED blinks blue. → Ready to pair.



#### **4.2 Beats Studio Pro**


- Turn on your headphones.
- 2 Press and hold the system button on the right earcup. LED **blinks**.
  - → Ready to pair.




#### 4.2 Sony WH-1000XM6

Press and hold **\$** for **5s**.


LED blinks blue. → Ready to pair.





### 4.2 Samsung Galaxy Buds

With earbuds in the case, close the lid and wait 5-6s.




② Open the case – They'll auto-enter pairing mode. → Ready to pair.

### 4.2 JBL Live Headphones


- Turn on your headphones.
- Press & hold the power button.

  LED blinks blue. → Ready to pair.



#### 4.2 Avantree Audition 3

- **1** Switch ON/OFF to Power.
- 2 Hold ON/OFF to Pair for 3s. LED blinks red & blue. → Ready to pair.



## 4.2 Other/Speaker

- Visit your headphone or speaker brand's support site
- Or Google "put [your headphone/speaker brand] in pairing mode"



put [your headphone/speaker brand] in pairing mode

#### 4.3 Power On Audikast 3

- Connect Audikast 3 to power (5V, 0.5-2A).
- Turn it **ON**. It auto-enters pairing mode: → LED ⇔ blinks red & blue.


If not, hold button (i) for 5s.




#### 4.4 Connect to Headphones

- Make sure your headphones and Audikast 3 are in pairing mode.
- 2 When connected, LED > stays blue.


Can't pair? Unplug the transmitter's power cable, then reconnect it.




Select audio source connection:



(Recommended)





#### 5.1 Connect the Optical Cable

Plug in the optical audio cable: Transmitter ↔ TV (Optical Out)





#### 5.2 Set TV Audio Output

- On your TV, set the sound output to **Optical** and audio format to **PCM** to avoid no sound.
- **2** Play a video. → LED OPT stays **white**.



See audio setup for Samsung, LG, Sony, TCL & Vizio, etc.

Next

#### 5.1 Connect the AUX Cable

Plug in the AUX audio cable:


Transmitter ↔ TV (Headphone/Audio Out)





#### 5.2 Set Up TV Audio

- 1 On your TV, set the sound output to **Headphones**.
- Play a video. → LED AUX stays **white**.



#### 5.1 Use the RCA Cable

- Use RCA ports labeled "AUDIO OUT" only.
- RCA adapter is **not** included.
   Need one? Contact us for a free adapter if needed





### 6.1 Reconnect Tips

- Turn off phone Bluetooth.
- Auto-connects to last device after turning on. If not, press (1) once.
- Still not working? Re-pair manually.

### 6.2 Add 2nd Pair Headphones

- With 1st pair connected, hold button for 5s. → LED 1 blinks red & blue. → Ready to pair.
- 2 Put 2nd pair in pairing mode.
- 3 When connected, both LEDs stay blue.



### 6.3 Dual-Link Reconnect Tips

- Turn off phone Bluetooth to avoid interference.
- Always auto-reconnects to last paired device. If not, press not once accordingly.
- Still not working? Re-pair manually.
- One side sound with earbuds?
   Put them back in the case and remove them.

#### 6.4 Use With TV Speaker


Some TVs let you play sound through **TV speakers** and **headphones** at the same time.

- Works by default on some models.
- Others need PCM + TV Speaker selected in settings.
- See FAQ for step-by-step help. ↗

#### 6.5 Reset

- 1 Turn on Audikast 3.
- Press and hold + & for 7s.
  → All LEDs stays on.
  This will clear pairings.

The transmitter will then enter pairing mode. → LED(1) blinks red & blue.



#### 6.6 Firmware Update

- Download Avantree Updater on your PC.
- 2 Plug in Audikast 4.
- **3** Install and run the app.
- 4 Follow the in-app steps.

**Important:** Reset Audikast 3 after the firmware update.

## 7. Recommend Use With

These products work great with your Audikast 3:



Audition 3



AS50Q



NB16-Q



Infinity



ShareCast Solo



AS70P

# 8. Troubleshooting

#### No sound?

Headphone connected?

Check LED @ :

- Solid = OK
- Flashing = Not connected
   → Fix it.
- Check: TV Audio Signal Valid?
   LED OPT/AUX:
  - Solid = OK
  - Flashing = No signal
     → Fix it.

More Troubleshooting & FAQ /

# 9. Register Your Product

Register now to:

- Get notified of firmware updates.
- Extend warranty to 24 months— FREE.
- Enjoy priority service support.

Register Now 7



# 10. Live Agent Help

We'll respond within **1 business day**Quick support options:

- Email: support@avantree.com
- → Schedule callback →
- **Submit** a ticket ↗
- □ Live Chat 
   ✓


## 11. Rate This Guide

Thanks for choosing Audikast 4!

We hope this guide helped you get started.

Your quick rating helps us improve:







#### 12. Advocate for Us

We've supported hearing-impaired customers for **20+** years.

Did we help you? Leave a quick review on Amazon to support us!

Select your store:

- M Amazon US
- M Amazon CA
- M Amazon AU
- Amazon UK